RFL® 9780/9785 One Rack Unit Hybrid Chassis Ordering Information

RFL Part Number (fill in blanks):	НҮВ	
Basic Transmitter/Receiver		
1 Rack Unit Chassis	HYB	
Left Position		
Blank Panels	В	
Transformer Hybrid	Т	
Skewed Hybrid	S	
Middle Position		
Blank Panels	В	
Transformer Hybrid	T	
Skewed Hybrid	S	
Right Position		
Blank Panels	В	
Transformer Hybrid	T	
Skewed Hybrid	S	
		-